

SDWISP POE Troubleshooting

Step 1.

Make sure the POE brick's power light is on.



Step 2.

Make sure the ethernet cable(YELLOW) is plugged into the router's WAN port and is connected to the LAN port on the POE brick.



Step 3.

Make sure the (black) cable going outside to the radio is connected to the POE port on the POE brick.

Step 4.

Verify the power cable from the POE is plugged into a wall socket. Also check the power cable for the router is plugged in. Look for Power light on the router.



